

# Paper Clip Fatigue

Katelyn Miller and Matthew Wilson

# Research Questions

- How does the temperature (colder, cold, room temperature) affect the number of times a paper clip can be bent before it breaks?
- How does the wire gauge (1mm vs. 0.8mm) influence paper clip fatigue?
- Does the person bending the paper clip have a different affect on paper clip fatigue?

# Data Collection



(a) Original form.



(b) Opened paper clip.



(c) Broken paper clip.

**Figure:** These three images depict different stages in the data collection process.

# Model

Let  $y_i$  be the number of bends required to break the  $i^{th}$  paper clip.  
Then,

$$y_i \sim \text{Poisson}(\lambda_i) \quad (1)$$





$$\log(\lambda_i) = \beta_0 + \beta_1 \text{temp}_i + \beta_2 \text{gauge}_i + \beta_3 \text{tester}_i \quad (2)$$

$$\beta_j \sim \text{Normal}(0, 100) \quad (3)$$

where  $i = 1, 2, \dots, 60$


where  $j = 0, 1, 2, 3$

# Draws from $\beta$




$\beta_1$ : (0.001 0.022)  $\beta_2$ : (-0.346, 1.702)  $\beta_3$ : (0.060, 0.448)

# Check Convergence




(a) Beta Trace plots




(b) Beta ACF

**Figure:** We conclude that our  $\beta$  have converged. They also all had a Gelman Diag. of 1



**Figure:** The distribution of goodness-of-fit p-values is good. Proportion below 0.05 is 0.04.

# Results



**Figure:** PPD depicting how many more bends it takes to break a 1mm paper clip versus 0.8mm.





# Results



**Figure:** Posterior predictive distribution of the difference in the number of bends until breaks for Testers 1 and 2.

# Results



(a) PPD 74°F compared to 42°F.    (b) PPD 100°F compared to 30°F.

**Figure:** Comparing the impact of cold versus hot temperatures in reasonable and extreme situations.

# Conclusion

- **Temperature:** Colder temperatures cause paper clips to break after fewer bends, suggesting increased brittleness.
- **Wire Gauge:** No significant impact was found between the 1mm and 0.8mm wire gauges on paper clip fatigue.
- **Tester Variability:** While the tester had some effect on results, it was not statistically significant.

## Summary:

- Temperature and tester identity influence paper clip fatigue.
- Wire gauge does not significantly affect performance.